





Internet Cube Camera

Quick Start Guide

## Appearance



Name	Description
Power Input	Micro USB interface for the power supply (5V ). Plug the power cable into the power input interface to power on the camera.
IR Light	Auto light source for night vision. The light is behind the anti-reflection panel. You can see the light when it is on.
Status Indicator	<ul style="list-style-type: none"><li>• Solid Red: Camera starting up.</li><li>• Slow-flashing Red: Wi-Fi connection failed.</li><li>• Fast-flashing Red: Camera exception (e.g. microSD card error).</li><li>• Fast-flashing Blue: Camera ready for Wi-Fi connection.</li><li>• Slow-flashing Blue: Camera running properly.</li></ul>




Name	Description
Memory Card Slot	For microSD card. If a memory card is used, video files will be stored in the memory card. You would need to initialize it via the My Home app.
RESET	RESET: Hold down the button for 4 seconds when the camera is running.


## Installation

### 1 Install the camera.

- 1 Paste the mounting template onto the installation surface.




- 2 Fix the mounting base to the installation position according to the holes on the mounting template.




3

- 3 Line up and wedge the lower edge of the camera base with the mounting base and then push the camera to the mounting base to secure it.



- 2 **i** Wall mounting is not recommended.
- 2 Adjust the surveillance angle.

- 1 Rotate the camera body to adjust the panning position.
- 2 Pull and push the camera body to adjust it to the desired tilting position.



1

2


4

## Operations

### Step 1

#### Power on the Camera

Connect the camera to the power adapter with the Micro USB cable, and then plug the power adapter into the power outlet. When the blue light flashes, the camera is powered on. You can set the Wi-Fi connection.



5

### Step 2

#### My Home Setup

- Connect your mobile device to Wi-Fi.
- Download and install the My Home app by searching the "My Home" in App Store or Google Play™. If you want to use AP function, download My Home v1.0.0 or above.

OR

- Launch the app and register for a My Home user account.
- i** Use of the product is subject to your registration with My Home and your agreement to the Terms of Service found at

6


### Step 3

#### Add the Camera to Your My Home Account

- i** Start the adding process only when the indicator flashes blue.
- Connect your mobile phone to a Wi-Fi (5G Wi-Fi is not supported yet).
- Log into the My Home app.
- In the Home page, tap "+" on the upper-right corner to add a camera.
- Scan the QR code on the bottom of the camera or on the Quick Start Guide cover.
- Follow the prompts to set the network connection and add the camera to your My Home account. (Locate the camera within 3 meters from the router when setting up the Wi-Fi.)

7

## Hình dạng bên ngoài




Tên	Miêu tả
-----	---------

Đầu vào nguồn	Nguồn đầu Micro USB (5V). Cắm cáp vào nguồn đầu vào để bật nguồn camera.
---------------	--

Đèn IR	Tự động bật vào ban đêm. Đèn sẽ sáng khi được bật.
--------	--

Đèn báo trạng thái	<ul style="list-style-type: none"> <li>● Đèn màu đỏ : Camera đang khởi động.</li> <li>● Đèn màu đỏ nhấp nháy chậm: Kết nối wifi không thành công</li> <li>● Đèn màu đỏ nhấp nháy nhanh: Ngoài trừ lỗi camera (ví dụ lỗi thẻ nhớ micro SD)</li> <li>● Đèn màu xanh: Camera hoạt động bình thường</li> </ul>
--------------------	--



Tên	Miêu tả
-----	---------


Khe cắm thẻ nhớ	Đối với thẻ nhớ microSD. Nếu thẻ nhớ được sử dụng, các tệp video sẽ được lưu trong thẻ nhớ. Bạn sẽ cần khởi tạo nó thông qua ứng dụng My Home.
-----------------	--

RESET	Giữ nút reset trong 04 giây khi camera đang chạy.
-------	---


## Lắp Đặt

### 1 Lắp đặt camera

- 1 Dán mẫu gắn lên bề mặt lắp đặt.




- 2 Cố định đế gắn vào vị trí lắp đặt theo các lỗ trên mẫu lắp.




10

- 3 Lắp camera vào đế gắn để cố định nó.



- 1 Không khuyến khích gắn tường.
- ### 2 Điều chỉnh góc giám sát.

- 1 Xoay thân máy để điều chỉnh vị trí lia máy.
- 2 Kéo và đẩy thân máy để điều chỉnh nó đến vị trí nghiêng mong muốn.



1

2


11

## Sử dụng

### Bước 1

#### Bật Nguồn Camera

Kết nối camera với adapter và dây cáp USB. Sau đó cắm adapter vào ổ cắm điện. Khi đèn xanh nhấp nháy thì camera được bật nguồn và có thể cài đặt kết nối wifi.



12

### Bước 2

#### Cài đặt My Home

- Kết nối thiết bị di động của bạn với Wi-Fi.
- Tải xuống và cài đặt ứng dụng My Home bằng cách tìm kiếm My Home, trong App Store hoặc Google Play. Nếu bạn muốn sử dụng chức năng AP, hãy tải xuống My Home v1.0.0 hoặc trở lên.

Hoặc

- Khởi chạy ứng dụng và đăng ký tài khoản người dùng.
- 1 Việc sử dụng sản phẩm phải tuân theo đăng ký của bạn với My Home và sự đồng ý của bạn với Điều khoản dịch vụ

13

### Bước 3

#### Thêm camera vào tài khoản My Home của bạn

- 1 Chỉ bắt đầu quá trình thêm khi đèn báo nhấp nháy màu xanh lam.
- Kết nối điện thoại di động của bạn với wifi (wifi 5G chưa được hỗ trợ).
- Đăng nhập vào ứng dụng My Home.
- Trong trang chủ, hãy nhấn vào "+" ở góc trên bên phải để thêm camera.
- Quét mã QR ở nhãn được dán dưới để camera hoặc trong hướng dẫn sử dụng
- Làm theo hướng dẫn để đặt kết nối mạng và thêm camera vào tài khoản My Home của bạn. (Xác định vị trí camera trong vòng 3 mét từ bộ định tuyến khi thiết lập wifi)

14